

APPENDIX R

The input receivers of every slave must be able to operate during every cycle to determine whether the signal on the bus is a valid request packet. This requirement leads to a number of constraints on the input circuitry. In addition to requiring small acquisition and resolution delays, the circuits must take little or no DC power, little AC power and inject very little current back into the input or reference lines. The standard clocked DRAM sense amp shown in Figure 11 satisfies all these requirements except the need for low input currents. When this sense amp goes from sense to sample, the capacitance of the internal nodes 83 and 84 in Figure_11 is discharged through the reference line 68 and input 69, respectively. This particular current is small, but the sum of such currents from all the inputs into the reference lines summed over all devices can be reasonably large.